WORK SAFELY TODAY

EACH RULE VIOLATION IS A POTENTIAL ACCIDENT

TRAINMASTER

J. E. KENADY Yuba City

TRAINMASTER—ROAD FOREMAN OF ENGINES

E. G. RATCLIFFE......Sacramento

CHIEF DISPATCHER

F. R. JUSTISSacramento

DISPATCHERS

E. L. COKERSacramento
J. E. TAYLOR Sacramento
J. L. BARRIER Sacramento
B. I. LONGSacramento

SACRAMENTO NORTHERN RAILWAY

TIMETABLE

27

AT 12:01 A. M.

PACIFIC STANDARD TIME

FOR THE GOVERNMENT AND INFORMATION
OF EMPLOYES ONLY

R. T. KEARNEY,

President and General Manager

H. J. MULFORD, Superintendent

FIRST SUBDIVISION

		East	ward				West	ward		
		SECOND	CLASS		Time Table No. 27	8 50	THIRD	CLASS		
	Symbols, Rule 6-A		2	Milepost	January 8, 1961	Distance from East Pittsburg	3		Capacity of Sidings in 50 ft. cars	Capacity of other tracks
	82 EX		Leave Daily	A	STATIONS	Dist	Arrive Daily		Ca 50	Cal
Yard Limits	PBK		6.00 AM	27.44	TO WALNUT GREEK	21,02	10.05 AM		10	50 E&W
	P		6.05	29,46	SPARKLE	19.00	9.57			7 W
			6.06	29.56	LAS JUNTAS (S.P.R.R.Orsg.)	18.90	9.56			5 W
	P		6.07	30.11	BANCROFT	18,35	9.54			8 W
Yard	P		6.10	31.02	MEINERT	17.44	9.52		37	15 W
Limits	P		6.13	32,13	CONCORD	16,33	9.50			8 E
	PAI		6.40	37.21	OLYDE (NAVAL R.R.Orsg.)	11,25	9.35			23 E
Yard Limits	P		6.45	39,03	PORT CHICAGO	9,43	9.30		13	41 E
	P		6.50	41,19	NICHOLS	7.27	9.23			15 W
Yard Limits	P		6.55	42,46	McAVOY	6.00	9.20		16	12 W
	P		7.00	43.59	SHELL POINT	4.87	9.15			2 W
	PY		7.05	44.92	WEST PITTSBURG	3,54	9.10		10	34 E&W
				46,24	AT&SF Crossing	2,22				
	PB		7.10 AM	46,95	TO PITTSBURG	1.51	9.00 AM			9 E&W
imits				47.39	AT&SF Crossing	1.07				
Yard Limits				48,06	AT&SF Crossing	0.40				
			Arrive Daily		(21.02)		Leave Daily			
	kets tion		(1.00 PM)	48,46	EAST PITTSBURG Jct. AT&SF	0.00	(8.00AM)		ickets	Yard
	shown in brackets is for information only.		(2.30 PM)		STOCKTON YARD		(7.00 AM)		shown in brackets is for information only.	Yard
	Time showr () is for		(4.00 PM)		SOUTH SACRAMENTO		(5.00 AM)		Time show	Yard

Movements between South Sacramento and Stockton Yard on Western Pacific are governed by Western Pacific Operating Department Rules and Special Instructions.

Movements between Stockton and Pittsburg on Santa Fe are governed by Santa Fe Operating Department Rules and Special Instructions.

Movements between West Pittsburg and East Pittsburg are governed by Rule 93.

		Eastv	vard				West	ward		
		THIRD (CLASS		Time Table No. 27		SECON	CLASS		
	Symbols, Rule 6-A	8	6	Milepost	January 8, 1961	Distance from Sacramento	7	9	Capacity of Sidings in 50 ft. cars	Capacity of other tracks
		Leave Daily	Leave Daily		STATIONS		Arrive Daily	Arrive Daily		
Yard		5.00PM	5.00AM	4.41	VAGAVILLE	41.24	4.30AM	4.30PM		33 E&W
Limits {	P.Y.	5.13	5.13	7.60	VACAVILLE JCT.	36.83	4.17	4.17		
	P.Y.	5.33	5.33	64.55	DOZIER 9.57	28.12	3.57	3.57	22	30 E&W
Yard Limits	P	5.53	5.53	74.12	LIBFARM	18.55	3.37	3.37	26	32 W
	P	5.55	5.55	75.23	YOLANO 4.48	17.44	3.35	3.35	42	
	P	6.05	6.05	79.71	SAXON 7.24	12.96	3.25	3.25	4	
Yard Limits	P	6.20	6.20	86.95	RIVERVIEW	5.72	3.10	3.10	40	
22	P.O.	6.30PM	6.30AM	91.56	WESTGATE 0.81	1.11	3.00AM	3.00PM		Yard
Yard Limits	P.Y.			92.37	BRODERICK 0.30	0.30				Yard
Yard	P.B.K.I.			92.67	SAGRAMENTO Front St. S.P.R.R. Crsg.	0.00				Yard
		Arrive Daily	Arrive Daily		(41.24)		Leave Daily	Leave Daily		

,		Eastwa	rd		HOLLAND BRANCH		West	tward				
		SECOND	CLASS			8	THIRD	CLASS				
	Symbols, Rule 6-A	Symbols, Rule 6-A	18	16	Mile Post	Time Table No. 27 January 8, 1961	oxford	17	19	Capacity of Sidings in 50 ft. cars	Capacity of	her tracks
	24	Leave Daily	Leave Daily		STATIONS	Dist	Arrive Daily	Arrive Daily	200	5	00	
Yard Limits	P	3.10PM	3.10AM	0.00	RIVERVIEW 5.89	15,77	4.50AM	4.50PM	40			
	P	3.25	3.25	5.89	OLARKSBURG	9.88	4.35	4.35	30	12	W	
	P	3.34	3.34	8.66	OENTRAL 1.85	7.11	4.26	4.26	32	4	E	
	P	3.40	3.40	10.51	GREENDALE 2.69	5,26	4.20	4.20	16			
	P	3.48	3.48	13.20	SORROCA 1.06	2.57	4.11	4.11	26			
	P	3.51	3.51	14.26	VALDEZ	1,51	4.08	4.08	21	11	E	
	P	3.55PM	3.55AM	15.77	OXFORD	0,00	4.05AM	4.05PM	15	19	w	
		Arrive Daily	Arrive Daily		(15.77)		Leave Daily	Leave Daily				

	East	ward	WILLOTTA BRAN	СН	Westwa	rd	
	Symbols, Rule 6-A	Mile Post	Time Table No. 27 January 8, 1961 STATIONS	Distance from Willotta	Capacity of Skilings in 50 ft, cars	Capacity of	other tracks
	Y.P.	7.60	VAÇAVILLE JÇT.	9.42			
		12.91	FAIRFIELD	4.11			
Its		14.83	SUVAL	2,19		11	W
Yard Limits		15.18	OHADBOURNE	1.84	12	11	W
Yard		15.89	RUSSELL 0.88	1,13		14	W
		16.77	DANIELSON 0.25	0,25	6	3	E
		17.02	WILLOTTA	0.00		12	W

	East	ward	MONTEZUMA BRA	NCH	Westwa	rd
	Symbols, Rule 6-A	Mile Post	Time Table No. 27 January 8, 1961 STATIONS	Distance from Dozier	Capacity of Sidings in 50 ft. cars	Capacity of other tracks
	P	49.98	MONTEZUMA	14,57		25 E
its	P	51.97	MOLENA	12.58	15	
d Limits	Р	57.78	RIO VISTA Jet.	6.77		10 W
Yard	P	60.78	OREED	3.77		2 W
	Y.P.	64.95	DOZIER	0,00	22	30 E&V

Train-order authority is not required on Willotta and Montezuma branches, and all movements on these branches must be made at yard speed.

Permission of the Train Dispatcher must be obtained before leaving Dozier on movements to Montezuma Branch and before leaving Vacaville Jct. on movements to Willotta Branch.

SECOND SUBDIVISION

		East	ward				Wes	tward				
		SECOND	CLASS				THIRD	CLASS				
	Symbols, Rule 6-A	22	20	Mile Post	Time Table No. 27 January 8, 1961	Distance from Bacramento	21	23	Capacity of Sidings in 50 ft. cars	Capacity of other tracks		
		Leave Daily	Leave Daily	Leave Daily	Leave Daily		STATIONS	_	Arrive Daily	Arrive Daily		
its	P.B.Y.K.	5.00 PM	5.00 AM	94.99	SACRAMENTO, B ST. Jet. W.P.R.R.	41.02	9.20 AM	9.20 PM		Yard		
Yard Limits	P.			95.49	MAGGIN, Jct. WPRR	40.52				Yard		
Yard	P.			96.44		39.57						
	P.	5.12	5.12	97.16	TOWER DISCOMMENDED	38.85	9.08	9.08		6 V		
	P.	5.17	5.17	98.99	DEL PASO	37.02	9.03	9.03		7 V		
Yard Limits	P.	5.26	5.26	103.10		32.91	8.54	8.54	35			
	P.	5.29	5.29	104.41	ELVERTA	31,60	8.51	8.51		5 V		
	P.	5.35	5.35	107.85	2.94 RIEGO 1.82	28.66	8.45	8.45		8 7		
	P.	5.40	5.40	109.17	SANKEY	26.84	8.40	8.40	25			
	P.			134.40	Jct. WPRR	3.71						
Yard	P.	10000		136.31	Jct. WPRR	0.96				Yard		
Limits	P.	6.35 PM	6.35AM	187.27	YUBA CITY S.P.R.R. Orossing	0.00	7.45 AM	7.45 PM		Yard		
		Arrive Daily	Arrive Daily		(41.02)		Leave Daily	Leave Daily	-			

Eastward

EAST NICOLAUS BRANCH

Westward

Movements on Western Pacific between Haggin and Globe and between Sankey and Marysville are governed by Western Pacific Operating Department Rules and Special Instructions.

Train order authority is not required on East Nicolaus and Pearson branches, and all movements on these branches must be made at yard speed.

Permission of the Train Dispatcher must be obtained before leaving Sankey on movements to East Nicolaus Branch and before leaving Alicia siding on movements to Pearson Branch.

	Symbols, Bule 6-A	Mile Post	Time Table No. 27 January 8, 1961	Distance from Sankey	Capacity of Bidings in 50 ft. ears	Capacity of	other tracks
			STATIONS				
lts	P. AI	109.17	SANKEY, W.P.R.R. Oross.	9.83	25		
Yard Limits	P.	114.75	CATLETT	4.25		36	E
Yar	P.	119.00	EAST NICOLAUS	0.00	17	31	W
			(9.83)				

Ea	astward	ii II	PEARSON BRANCH	Westward			
	Bymbols, Rule 6-A	Mile Post	Time Table No. 27 January 8, 1961	Distance from Pearson	Capacity of Sidings in 50 ft. cars	Capacity of other tracks	
			STATIONS				
ts.	P.	129.70	PEARSON	4.70	5	32 E&W	
Yard Limits	P.	132.36	ALIOIA	2.04	25	8 W	
Yard	P.	134.40	WP MP 175.63 Jct. WPRR	0.00			
			(4.70)				

SECOND SUBDIVISION

		Eastwa	ard				Wes	stward			
		SECOND	CLASS				THIRD	CLASS			
	Symbols, Rule 6-A	26	24	Milepost	Time Table No. 27 January 8, 1961	Distance from Yuba City	25	27	Capacity of Sidings in 50 ft. cars	Capacity of	other tracks
		Leave Daily	Leave Daily		STATIONS	Q	Arrive Daily	Arrive Daily			
Yard Limits	P.O.K.B.	6.00 PM	6.00 AM	137.27	YUBA CITY	47.08	6.35AM	6.35 PM		Ya	rd
ard I	P.	6.03	6.03	138.56	PALORO	45.79	6.32	6.32		40	w
-	P.	6.05	6.05	139.43		44.92	6.30	6.30	25	28	w
Yard Limits	P. Y.	6.06	6.06	139.77	COLUSA JUNCTION	44.58	6.29	6.29			
	P.	6.13	6.13	143.62	SANDERS	40.73	6.21	6.21		7	W
Yard Limits	P. AI	6.25	6.25	149.31	LIVE OAK S.P.R.R. Cross.	35.04	6.10	6.10	20	25	E
	P.	6.35	6.35	154.39	EAST GRIDLEY	29.96	5.59	5.59	10	28	w
	P.	6.39	6.39	156.06	PEACHTON 6.12	28.29	5.55	5.55		7	E
	P.	6.51	6.51	162.18	LORRAINE 15.11	22.17	5.43	5.43		9	W
	P.	7.22	7.22	177.29	DURHAM 4.25	7.06	5.13	5.13		15	w
	P.	7.32	7.32	181.54	SPEEDWAY 0.48	2.81	5.03	5.03	12		
9	P.	7.33	7.33	182.02	STIRLING JOT., S.P.R.R. Oros	2.33	5.02	5.02			
Yard Limits	P.Y.	7.35	7.35	183.03	MULBERRY 0.34	1.32	5.00	5.00		Yar	rd
fard				183.37	CHICO 16TH ST.	0.98				Yaz	rd
	P. B. K.	7.45 PM	7.45 AM	184.35		0.00	4.50 AM	4.50M		Yar	rd
		Arrive Daily	Arrive Daily		(47.08)		Leave Daily	Leave Daily			

SECOND SUBDIVISION

		Eastwa	rd	WC	OODLAND BRANC	H	Wes	stward			
		SECOND CLASS	Time Table No. 27	m.	THIRD CLASS						
	Symbols, Rule 6-A	12	10	Mile Post	January 8, 1961	Distance from Woodland	11	13	Capacity of Sidings in 50 ft, cars	Capacity of other tracks	
		Leave Daily	Leave Daily		STATIONS		Arrive Daily	Arrive Daily			
Yard Limits	P.	6.30 PM	6.30AM	0.00	BRODERICK	16.57	8.10AM	8.10PM		Yard	1
	AI	6.34	6.34	1.55	MIKON. S.P.R.R. Cross.	15.02	8.06	8.06			
	P.	6.37	6.37	2.73	LOVDAL	13.84	8.03	8.03	14		
	P.	6.52	6.52	9.68	6.95 FREMONT 2.13	6.89	7.48	7.48	15		
Yard Limits	P.	7.00	7.00	11.81	CONAWAY	4.76	7.40	7.40		30	E
	P.	7.06	7.06	14.80	HEBRON	1.77	7.34	7.34		10	W
Yard Limits	P.	7.10 PM	7.10AM	16.57	TO WOODLAND	0.00	7.30AM	7.30 PM		Yard	1
		Arrive Daily	Arrive Daily		16.57)		Leave Daily	Leave Daily			

	Eastward	M	ERIDIAN BRANC	H	Westward			
	Symbols, Rule 6-A	Mile Post	Time Table No. 27 January 8, 1961	Distance from Meridian	Capacity of Sidings in 50 ft. cars	Capacity of other tracks		
			STATIONS					
1	P.Y.	0.00	COLUSA JUNCTION	13.64				
its	P.	5.24	TO SUTTER	8.40	14	35 E&W		
Limits	P.	10.28	TARKE	3.36	24			
Yard	P.	12.18	BEET SPUR	1.46	24			
	P.	13.64	MERIDIAN	00.0		18 W		
			(13.64)					

Train order authority is not required on Meridian Branch and all movements on the branch must be made at yard speed.

Permission of the Train Dispatcher must be obtained before leaving Colusa Jct. on movements to the Meridian Branch.

SPEED RESTRICTIONS — in miles per hour apply as follows:

LOCATION

EXPORT CYTER VILLETON BOSON I and 9	
FIRST SUBDIVISION — Pages 1 and 2 Walnut Creek, Yard limits between MP 26.9 and)TT
MP 27.6	d Flag
(See Special Rule on Page 7) Walnut Creek, Trinity Ave., MP 27.4Stop an	d Flag
(See Special Rule on Page 7) Walnut Creek, Highway Crossing, MP 28.020 MF	H
Las Juntas, MP 29.56 SP CrossingStop (See Special Rule on Page 7)	
Concord—City limits between MP 33.40 and MP 34.9615 MF	H
MP 36.04 to MP 37.21—Eastward trains descending Ohmer grade	H
Clyde—MP 37.21 U. S. Naval RR Crossing	$^{\mathrm{PH}}$
Port Chicago, Main St., MP 39.2Stop an	d Flag
(See Special Rule on Page 7) Nichols, Road Crossing, MP 41.015 MP	
Shell Point — MP 43.59 SP CrossingStop	
(See Special Rule on Page 7) West Pittsburg — Underpass curve between MP 44.02	
and MP 44.50	
MP 48.06	H
(See Special Rule on Page 7)	
Pittsburg — All street crossings	H d Flag
(See Special Rule on Page 7) Pittsburg — Columbia Street, MP 47.98Stop an	
ATSFe crossing East of Columbia Street, MP 48.06Stop an	d Flag
(See Special Rule on Page 7) Between Vacaville Jct., MP 7.60 and Vacaville, MP 4.4120 MP	H
Vacaville MP 4.3 Highway crossing protected by flashing light signals	on
Sacramento, MP 92.4 Highway Crossing west end	
Tower Bridge	
MP 92.6	Н
Movements governed by flagmanStop (See Special Rule on Page 7)	
Montezuma Branch, Page 2:	
Gum Grove, Highway crossing, MP 53.9Stop (See Special Rule on Page 8)	
Willotta Branch, Page 2: Between Vacaville Jct. MP 7.60 and Willotta	
MP 17.0220 MP	H
MP 10.6, Highway CrossingStop (See Special Rule on Page 8)	
MP 11.6, Highway CrossingStop (See Special Rule on Page 8)	
Holland Branch, Page 2:	
Between MP 86.95 and MP 15.77 all curves	H
(See Special Rule on Page 8)	••
Sacramento Belt Line	
Sacramento, City Limits between MP 92.55 and MP 95.15	H
Except — All street intersections	
engines	H
Exception — Does not apply to arterial stop located at Front Street and Capitol Avenue.	
Sacramento — Traffic light signals All movements governed by signal indication	
Sacramento — Street intersections	
When traffic officer on duty, all movements governed by traffic officer signals.	

Swanston Line North Sacramento, Del Paso Blvd., Crossing No. 8E-0.5 Stop	
CECOND CUDDIVICION Pages 2 and 4.	
SECOND SUBDIVISION — Pages 3 and 4: Sacramento, "B" Street, MP 94.99 Jct. WPRR	
MP 134.3 — Arboga Highway crossing protected by	
flashing light signals	
MP 175.63)	
Eastward trains and yard engines	
Marysville, All street crossings	
Yuba City, SP Crossing, MP 137.08Stop Except when proceed signal is received from flagman	
Yuba City, Cooper Avenue, MP 137.7Stop Yuba City, Street intersections —When traffic officer on duty all movements governed by traffic officer	
signals.	
Sanders, MP 143.8 Road Crossing	
Live Oak, SP crossing MP 149.31	
crossing	-
MP 161.4 Road crossing in cut east of Hazelbusch	
Stirling Jct. SP crossing MP 182.02	
Woodland Branch, Page 5:	
MP 2.1 Rose Orchard, highway crossing —Trains must reduce to 20 MPH 300 feet from crossing and speed must not exceed 15 MPH when head	
end of train moves over the crossing	
MP 8.0 Kiesel Highway crossing	
MP 10.17 and MP 11.71 Fremont Trestle15 MPH	
Woodland City Limits, MP 16.24 to end of tracks12 MPH Woodland, MP 16.4, Road crossing Shell Oil Plant 6 MPH	
Meridian Branch, Page 5:	
MP 1.6 Alamendra road crossing	
Speed Restrictions — General	
Maximum speed through turnouts, crossovers, on sidings and other inside tracks	
Approaching and passing over spring switches12 MPH Trains handling loaded air dump cars25 MPH	
Trains handling steam shovels, derricks, cranes or pile drivers on own wheels	
Maximum permissible speed, Trains and engines30 MPH Speed restriction sign located at various places where speed shall be reduced must be observed.	-
Speed permitted by city ordinances within city	
limits as shown in above speed restriction table does not dispense with the observance of Rule 93.	

FIRST SUBDIVISION

Walnut Creek, Bonanza St., Crossing No. 8-27.3; Walnut Creek, Trinity Ave., Crossing No. 8-27.4:

Stop boards are located on both sides of these crossings. No train, motor, engine or car shall be operated over these crossings without first having been brought to a stop and unless traffic on the highway be protected by a member of the train crew or other competent employee acting as a flagman.

Trains originating at Walnut Creek must obtain a clearance.

Southern Pacific Crossing at Las Juntas (MP 29.56) is protected by Stop Boards. All trains, engines, motors and cars must stop at stop boards and signal 14-B sounded before proceeding over the crossing, providing that there is no locomotive, motor, train or car of the Southern Pacific approaching the crossing from either direction.

When view is obscured by fog or inclement weather, a member of the crew must go forward to the crossing and ascertain that no train is approaching on the Southern Pacific Railway before pro-

ceeding over the crossing.

Port Chicago, Main St., Crossing No. 8-39.2:

Stop boards on both sides of crossing.

All trains, engines, motors or cars must come to a stop and no movement made over the crossing until a member of the train crew has protected traffic on the crossing.

Signs reading—Cars must not be switched beyond this point by S. P. Co. - S. N. Ry. — are located on track 1 at the Shell Chemical Plant, Shell Point.

During periods of heavy fog or when visibility is restricted, sound crossing whistle when approaching and before passing over private roadway northeast corner Shell Chemical plant, Shell Point.

Westward trains originating at West Pittsburg will report their departure to the Train Dispatcher.

A two-indication color light train order signal is located on the depot building at Pittsburg. This signal governs movements in the

westward direction only.

The signal will indicate "stop" when there is an operator on duty, except when changed to indicate "proceed" to allow a train or engine to pass when there are no train orders for any train or engine in the westward direction. When the signal is dark, the office will be considered a closed train order office.

Westward trains and engines must call for the signal, except

when it indicates a closed office.

The tracks at the Shell Chemical Company's plant at Shell Point are used jointly by the Sacramento Northern and Southern Pacific. All movements over these tracks must be made with caution. The tracks leading from the Sacramento Northern and from the Southern Pacific cross at grade. All trains, motors, engines or cars of the Sacramento Northern shall stop at the "STOP" signs located at each approach to the crossing, and shall not proceed over the crossing until it has been ascertained that it is safe to do so. Several derails, properly signed, are installed on the various tracks.

A gate has been installed on the Santa Fe track which crosses the Sacramento Northern main track at MP 46.24, Pittsburg. This gate is equipped with a Santa Fe switchlock and a switch lamp is

mounted at the top of the mast supporting the gate.

This gate normally shall be locked in position across the line of railroad of The Atchison, Topeka & Santa Fe Railway Company and all trains, motors, engines and cars of The Atchison, Topeka & Santa Fe Railway Company shall stop before proceeding across said crossing and said gate shall not be unlocked and moved from its normal position until a member of the train crew or other competent employe has gone upon the crossing to ascertain that it is safe to do so. As soon as trains, motors, engines and cars of The Atchison. Topeka & Santa Fe Railway Company have proceeded across said crossing, such gate shall be returned to its normal position.

Trains, motors, engines and cars of Sacramento Northern Railway shall approach said crossing at speeds not in excess of fifteen (15) miles per hour, prepared to stop in the event such crossing is occupied by trains, motors, engines or cars of The Atchison, Topeka & Santa Fe Railway Company or in the event such gate is in other than its normal position, and one long blast of the engine whistle shall be sounded by the Sacramento Northern Railway when approaching said crossing in accordance with Rule 14 (M)

Distance warning signs located 1000 feet from crossing.

Sacramento Northern industrial lead taking off of the main track approximately 34 mile west of Pittsburg crosses industrial lead track of A. T. & S. F. Ry. at grade.

All engines, motors, cars or trains approaching the crossing shall come to a stop not less than ten (10) nor more than fifty (50) feet from nearest rail of the crossing and shall not proceed thereafter until receiving an appropriate signal from a flagman or other qualified employee. Such signal shall not be given until it has been definitely ascertained that no engines, motors, cars or trains are approaching from either direction on the conflicting route under conditions which will render it possible for an interference to occur with the movement about to be made over the crossing.

The A. T. & S. F. Ry. have precedence in the use of the crossing.

A. T. & S. F. Ry. crossing east of Harbor Street, MP 47.39, Pittsburg, is protected by stop boards. All engines, trains, motors and cars must come to a stop at the "STOP" boards located on either side of the crossing and no movement made over this crossing until a flagman has preceded over the crossing and ascertained that it is safe to proceed. A. T. & S. F. Ry. have the preference at this crossing.

At a point 360 feet east from the curb line of Columbia Street. MP 48.06, Pittsburg, a rail crossing at grade over the Atchison, Topeka & Santa Fe Railway lead track is installed. The following

instructions will govern in operating over this crossing.

All trains, motors, engines and cars of the Sacramento Northern Railway, the Atchison, Topeka & Santa Fe Railway, and Columbia Steel Company shall come to a stop not less than ten feet (10') nor more than fifty feet (50') from the nearest rail of the crossing, and shall not proceed thereafter until a member of the train crew or other competent employee has gone upon the crossing and has ascertained that it is safe so to do and shall have given a suitable signal to proceed. In event the trains, motors, engines and cars of either railroad have approached the crossing and made the stop, as hereinbefore required, and any trains, motors, engines and cars are approaching upon the conflicting route within a distance which will render them in any way liable to conflict with the movement over the crossing about to be made, such movement shall not be made until the trains, motors, engines and cars approaching upon the conflicting route have been brought to a stop.

Southern Pacific Railroad crossing at Front and Capitol Ave.,

92.67, Sacramento, is protected by flagman.

Southern Pacific trains moving on Front Street, Sacramento, and yard engines switching on Front Street, shall stop before reaching the crossing at Front and Capitol Ave., and will proceed on hand signals from flagman on the ground at the crossing, flagman using a green flag by day and green light by night. Sacramento Northern trains and yard engines moving over the

crossing shall stop before reaching the crossing at Front and Capitol Ave., and will proceed on hand signals from the flagman using a

yellow flag by day and a yellow light by night.

Rules governing movements over the SP crossing at Front and Capitol Avenue and movements through the interlocking plant on the Tower Bridge require that all movements over the SPRR. crossing are authorized by the flagman, using a yellow flag by day and a yellow light by night, and Rule 628 authorizes the signalman (tower operator) to use yellow signals whenever the interlocking signals are inoperative, therefore, when the interlocking signals are inoperative, engineers must receive a hand signal from the signalman (tower operator) in addition to the hand signal from the flagman. both using yellow signals.

Trains and yard engines approaching highway crossing on Westside lead, west of Tower Bridge, Sacramento, will allow not less than twenty (20) seconds to elapse from time flashing light signals start operating before engine or cars enter the highway traffic lanes.

FIRST SUBDIVISION (Continued)

The Sacramento-Yolo Port Belt Railroad crosses the Soule spur track of Sacramento Northern Railway at grade in Westgate, Sacra-

mento Yard.

All engines, cars or trains of the Port Belt Railroad shall come to a stop not less than ten (10) feet nor more than fifty (50) feet from the nearest rail of said crossing and shall not thereafter proceed until it has been observed or it is known that no engines or cars are approaching from either direction on the conflicting route under conditions which will render it possible for an interference to occur with the movement about to be made over the crossing. The engines or cars of Sacramento Northern Railway shall have precedence in the use of this crossing.

These regulations apply to Sacramento Northern Railway engines and cars when movements are made on the Port Belt Railroad.

Stop boards are located in advance of crossing on the Port Belt Railroad.

Westward trains will report arrival at Riverview.

HOLLAND BRANCH, Greendale, Highway Crossing No. 8J-9.9:

Movements of trains, engines, motors or cars approaching this highway crossing are restricted to twenty (20) MPH 800 feet from crossing.

MONTEZUMA BRANCH, Gum Grove Highway crossing No. 8-53.9, approximately 3.9 miles west of Rio Vista Jct.:

No train, motor, engine or car shall be operated over this crossing without first having been brought to a stop before entering the crossing. Proceed with caution.

WILLOTTA BRANCH, MP 10.6, HIGHWAY CROSSING No. 8F-10.6:

All trains, engines and cars must be brought to a stop before entering this highway crossing and wait not less than twenty (20) seconds after highway flashing light signals start operating before proceeding over crossing.

Fairfield Willotta Branch, MP 11.6:

North Texas Street, Fairfield - All trains, engines, motors or cars must come to a stop, and no movement made over the crossing until a member of the train crew or other competent employee acting as a flagman has protected traffic on the crossing.

After stopping and when traffic on the crossing permits and it is safe to proceed, the employee acting as flagman shall display lighted fusee from front end of the deck of the engine both during the daylight and at night, until the engine passes over the crossing.

SECOND SUBDIVISION

Pearson, MP 130.9, Highway Crossing:

All trains, engines and cars must come to a stop and no movement made over the crossing until a member of the train crew, or other competent employee, acting as a flagman, has protected the traffic on the highway. After stopping, and when traffic on the highway permits, and it is safe to proceed, the employee acting as a flagman shall display a red flag by day and a lighted red lantern by night from the leading end of engine or car until front end of engine or car passes over the crossing.

BLOCK SIGNALS

Automatic block signals between Marysville and Yuba City:

Two indication color light home signals located as follows: Signal 190 feet east of junction switch opposite Marysville depot governs eastward movements.

Signal 1074 feet west of Yuba City depot governs westward

movements.

Movement of trains and yard engines within home signal limits will be made in accordance with indication of signals subject to the following regulations:

Flashing white light located on track side of Yuba City depot is to apprise trains and yard engines of condition of route between home signals. When flashing, route is unoccupied.

Before proceeding from Yuba City depot to Marysville, member of crew shall press push button mounted on pole adjacent to west crossover switch near Yuba City depot which holds route for westward movements for a period of ten (10) minutes and causes flashing light to burn steadily. Train or yard engine may then proceed, being governed by indication of home signal.

The following regulations apply to movements on Main Street, Chico:

Trains, cuts of cars, or single cars or locomotives shall not be permitted to stop or stand on any track located in Main Street, except to do so for vehicular traffic, traffic signals, or in the event of emergencies such as derailments, mechanical failures and the like.

Train and engine movements are prohibited on Main Street, Chico, between the hours of 7:00 a.m. and 7:00 p.m., except during the period when Daylight Saving Time is in effect commencing with the last Sunday in April to the last Sunday in September each year, train and engine movements are prohibited on Main Street, Chico. between the hours of 6:00 a.m. and 6:00 p.m. (PST).

Freight trains are limited to engine and 20 cars on Main Street,

Trainmen must not ride on top or side of cars in the area between Sacramento Avenue and 5th Avenue on the Esplanade, Chico.

In addition to displaying a red light to the rear as required by Rule 18-Modified, a lighted red fusee must be placed at the rear of all eastward movements on city streets at Chico.

Amber revolving light mounted on top of engine will be displayed for all movements within Chico yard limits. If amber light is inoperative or when using an engine not equipped with amber revolving light, a lighted red fusee will be displayed on leading end of engine in direction of movement.

GENERAL

RULE 10-H, first paragraph—Amended:
A metal banner at right of track displaying yellow indicates that trains must reduce speed over track to 10 miles per hour until rear of train has passed temporary resume speed signal unless otherwise directed by train order or bulletin. Such signal must be placed one-fourth (¼) mile before the location is reached where speed of trains must be reduced.

RULE 17-C. Headlights must be dimmed while moving within city limits.

RULE 18-Modified. Yard engines when making a continuous movement along city streets will not display the headlight at the rear by night. A red light must be displayed to the rear, and on the rear of the last car when cars are being handled.

It shall be the responsibility of the rear brakeman to see that a red light is continuously displayed at the rear until movement is

completed.

When stop is made and train or yard engine is left standing in street, trainman will place lighted fusee in street at rear of cut. When necessary for trainman to leave rear of cut and go ahead one or more lighted fusee will be dropped in street.

Rule 21 of the Operating Department Rules is suspended.

RULE S-72. Westward trains are superior to Eastward trains of the same class.

RULE 82-A—Amended. Regular trains will be authorized at their initial stations and at intermediate stations by permission of the Train Dispatcher. A written clearance is not required unless train orders are issued to regular trains.

Rule 93 permits the main track to be used in yard limits: therefore enginemen approaching yard limits where the view of the yard limit board is more or less obstructed account of curves or cuts (like the board in the East end of the yard at Walnut Creek) must be mindful of this rule and approach the yard limits with caution, expecting to find the main track occupied and without flag protection.

RULE 103 (B). Public streets and highway crossings must not be blocked longer than necessary and in no case longer than five (5)

Back-up hose must be used by crews when shoving more than five cars ahead of engine over city streets.

GENERAL (Continued)

Second paragraph of Rule 15, Air Brake Rules, on Page 88 of Operating Rule book effective May 1, 1958, is amended as follows: Standard Brake Pipe Pressure: Freight and mixed trains, 90 pounds, and passenger trains including RDC cars, 110 pounds. Minimum differential brake pipe and main reservoir with brake valve in running position, 15 pounds.

Air must be cut in and air brakes in operation on all yard cuts, and on trains within yard limits, when moving over and along city streets except when doing station work or yard switching.

Air must be cut in and air brakes in operation on all yard cuts, and on trains within yard limits, when moving or working on grades where air brakes are necessary to keep cars under control.

During and immediately following stormy weather which may impair the roadway, Engineers must take extraordinary precautions to insure safe movement of their train, reducing speed where in their judgment it may be required.

Amber revolving light mounted on top of engine and the oscillating headlight may be used when in the judgment of the engineer their use will provide additional protection for train and yard movements, except that the amber revolving light must not be displayed on Western Pacific tracks at any time.

City Ordinances require all trains and yard engines within one hundred feet of an intersection to stop immediately on the approach of any police, ambulance, or fire apparatus sounding siren or signal gong except they be at the time on, or crossing an intersection, in which event crossing must be cleared and then stop.

Civil, Military or Funeral processions must not be obstructed.

When trains and yard engines approach a street intersection simultaneously, except where traffic is controlled by traffic signals in service or by traffic officer, the train or yard engine moving eastward must reduce speed, stopping if necessary, and must not enter the intersection until the train or yard engine moving in the west-ward direction has passed entirely out of the intersection or has completely blocked the intersection, thus preventing vehicular traffic from crossing the tracks.

Movement over street intersections or around sharp curves in switching service when the engineer's view (or the fireman's view if working on the fireman's side) is obstructed must be protected by a member of the crew acting as a flagman. The conductor is jointly responsible with the engineer for this protection being given.

Conductor will see that trainmen are so distributed over the train as to control it most effectually and be able to pass signals from any part of it to the enginemen. This rule applies to continuous movements over and along city streets and in yards, and where required a trainman must take a position at the rear of yard cuts.

To reduce automobile accidents, special care should be used when approaching grade crossings known to be obscured or hazardous. Where vehicles are moving in public streets in the same direction as the train and are not clear of the track on which train is operating, speed should be so controlled as to permit train being stopped in case vehicle makes a sudden or unexpected stop or turn. When about to pass a vehicle moving in the same direction as train, the engineer should satisfy himself that the driver is aware of approach of the train.

The following instructions cover the use of push poles:

(a) The use of push poles in freight operations is prohibited, except in emergencies when poling of cars cannot otherwise be

avoided.

(b) When such emergencies arise and it becomes absolutely necessary to pole cars, as quickly as pole is in position, member of crew placing pole must move into the clear a sufficient distance to insure his personal safety; being careful to place pole in pole pocket or in such position that pole will not slip. Such poling movements must be executed with great care and without cars coupled to engine, being careful to avoid misunderstandings of signals or damage to equipment. The use of non-standard push poles is strictly prohibited.

Cars of gasoline when spotted for unloading at any oil spur must be left between the insulated joints and the end of the spur. No cars are to be left standing over the insulated joints or coupled to cars spotted between the insulated joints and end of spur.

Where power switches are installed on gasoline unloading tracks, they must not be closed until it has first been ascertained by a member of the crew that all cars have been disconnected and are ready to move. The power switches must be left open after switching has been completed.

The trolley or pantograph must be down before removing any jumpers, handling 600-1200 volt switches, or when the engineer is

repairing electrical equipment.

Should the pantograph become damaged so as to render it in-operative it must be locked or tied down and the pole trolley used instead. Should the damaged pantograph require repairs in order to lock or tie it down, extreme caution must be used to prevent the pantograph coming in contact with the trolley wire while repairs are being made.

Engineers must shut off power at all sectional insulators in trolley except at places where insulators have been designed for pantograph operation.

SACRAMENTO BELT LINE

Trains and yard cuts must stop and flag before crossing the SP and WP tracks at Front and R Streets except when a proceed signal is received from flagman. This rule means that trains must actually stop and be flagged over the crossing by a member of the crew unless a flagman is at the crossing in advance of the arrival of the train.

When Sacramento Northern trains and engines are moving on WP tracks on Front Street and R Street, they must stop before crossing the SN tracks on Front Street as provided for in WP

Transportation Rule 98.

All movements from point of switch to CPC Box Lot spur, Broadway side, Front and X Streets, Sacramento, will be made with caution not exceeding four (4) miles per hour.

JOINT TRACK

Sacramento Northern trains and engines use Santa Fe tracks

between Stockton and Pittsburg.

Trainmen and Enginemen using Santa Fe tracks will be governed by Santa Fe Operating Department rules and must have copy of current Santa Fe Operating Department Book of Rules, copy of current Santa Fe, Valley Division, timetable, and Santa Fe switch key in their possession at all times while on duty on Santa Fe.

The tracks on X Street and Front Street, Sacramento, are operated jointly with the C. C. T. Company.

Sacramento Northern trains and engines use Western Pacific tracks as follows:

Between South Sacramento and Stockton yard.

R Street line, Sacramento, between Front Street and east wye switch at WP MP 138.2.

Between WP MP 138.2 and Globe.

Between Sankey and Marysville.

Trainmen and enginemen using Western Pacific tracks will be

governed by Western Pacific Operating Department rules and special instructions and must have copies of current Western Pacific Operating Department Book of Rules, current Western Pacific, Western Division, Timetable, and current Western Pacific Air Brake Rules and Regulations in their possession when on duty on Western Pacific.

The WP tracks on Front and R Streets leading to the C. P. C. Plant may be used by SN yard crews under yard rules. WP yard engines have preference on these tracks.

On eastward movements from Haggin, inform Western Pacific

dispatcher by telephone when ready to leave.

On westward movements from Globe, inform Western Pacific

dispatcher by telephone when ready to move.

Telephones for communication with dispatcher are located near main track or junction switches.

Lunar White marker at east switch Haggin, WP MP 139.8:

Lunar white marker displayed in connection with aspect per Rule 287 on westward absolute signal at east switch Haggin indicates that switches are lined for movement to Sacramento Northern

When aspect per Rule 287 is displayed without display of lunar

white marker it indicates switches are lined to siding.

JOINT TRACK (Continued)

Eastward SN trains and engines at Haggin must contact train dispatcher for instructions to move Haggin to Globe. It will not be necessary to obtain similar instructions at SN-WP connection at Sankey for movement beyond if leaving signal on SN displays a proceed indication.

When Westward SN trains or engines at Marysville have contacted train dispatcher for instructions to move Marysville to SN-WP connection at MP 175.63 or Sankey, it will not be necessary to obtain similar instructions at Globe for movement beyond, except to obtain permission to operate electric lock.

The tracks in Haggin Yard, Sacramento, are used by Western Pacific yard engines and crews when switching their cars to and from Southern Pacific interchange. WP crews will contact the SN yardmaster before using these tracks and be governed by his instructions. These tracks are within yard limits.

Sacramento Northern Crews Marysville:

(See SPECIAL INSTRUCTIONS IN CURRENT WESTERN PACIFIC, WESTERN DIVISION, TIMETABLE.)

Telephones for communicating with train dispatcher are located

adjacent to all electric locks and signals.

Trains and yard engines must have permission from the West-

ern Pacific dispatcher to enter the siding at Marysville.

Westward trains and engines must stop to clear the passing track at Marysville and contact the Western Pacific dispatcher before entering the siding.

Trainmen must not leave master switch or crossovers at Marysville in other than normal position on Western Pacific control system unless they are working in the immediate vicinity.

Junction switch on siding at Marysville must be locked for

siding when not in use.

All movements on siding at Marysville must be made at yard speed.

The following instructions govern the use of Western Pacific telephone circuits: When calling the train dispatcher at Sacramento on either the train dispatcher's circuit or code line telephone, discontinue the practice of first saying "Dispatcher." The person calling, as well as the dispatcher, should follow the formula outlined below: Person Calling—"West Merlin," Dispatcher's reply—"Dispatcher," Person Calling—"Conductor Jones, West Merlin, Exa. 905 West."

Before calling on any telephone, first listen to make sure the dispatcher is not busy on the line; if he is not busy, then follow the

procedure outlined above.

JOINT TRACK, SACRAMENTO

Southern Pacific has trackage rights over SN Ry. track in Sacramento yard between Sacramento Yolo Port Railroad connection east of Washington underpass and connection to Sacramento Yolo Port Railroad east of county road crossing at Broderick. These tracks will be used jointly by SN Ry. and SP Co. crews. Movements on joint track will be governed by block signals whose indications supersede the superiority of trains.

Automatic signals located as follows:

Westbound

Woodland Branch 169 feet east of Sacramento Yolo Port RR connection switch-Washington.
Clear point Sacramento Yolo Port RR connection east of of Washington underpass.

234 feet west of east wye switch Woodland Branch. Clear point Sacramento Yolo Port RR connection. 37 feet east of west wye switch connecting with Oakland main track, Broderick.

Westbound distant signal displaying steady yellow indication located 3327 feet east of westbound automatic signal on Woodland Branch 169 feet east of Sacramento Yolo Port RR connection switch.

Washington. Indicators located at switches show condition of the joint track with regard to occupancy and switches are equipped with joint SN Ry. - SP Co. switchlocks. Before fouling joint track, member of crew required to handle switch must observe and respect the indi-

When indicator shows block clear switch may be reversed and movement started when yellow aspect is displayed by the signal.

If indicator shows block occupied, switch must not be reversed until it is known that there is no opposing or conflicting movement.

If after switch has been reversed signal displays Stop indication (Red aspect or light is not displayed in signal), train or engine must wait five minutes and then be preceded by flagman through joint track area.

Maximum speed permitted on joint track is ten (10) MPH and

all movements must be made with caution.

Normal position of switches connecting with joint track is as

Sacramento Yolo Port Railroad connection east of Washington underpass lined for Woodland Branch.

East Wye switch, Woodland Branch, lined for movement west leg of wye.

Sacramento Yolo Port RR connection east of county road cross-

ing, Broderick, lined for west leg of wye.

West wye switch connecting with Vacaville main track, Broderick, is normally lined for movement on the main track. Signal governing movements on west leg of wye is normally dark. Train or engine using main track must determine that the wye switch is in normal position after which dark signal may be passed without

Sacramento Yolo Port Railroad yard tracks will also be used jointly by SN Ry. and SP Co. crews and all movements must be

made with caution not exceeding ten (10) MPH.

Flag protection to rear is not required when operating in joint track area or over Sacramento Yolo Port Railroad yard tracks.

INTERLOCKING PLANTS AND SIGNALS

MP 37.21, CLYDE, NAVAL AMMUNITION DEPOT RAIL-ROAD CROSSING, INTERLOCKING.

Home signal located 610 feet east of crossing governs move-ment of trains over the crossing westward. Home signal located 578 feet west of crossing governs movement of trains over the crossing eastward. The westward distant signal is located 2410 feet in advance of the home signal. The eastward distant signal is located 3269 feet west of the home signal.

Distant signals are permanently lighted and display yellow aspect only per Rule 285, "Proceed, preparing to stop at next signal,"

not exceeding fifteen (15) MPH.

When train approaches the crossing and enters the approach circuit, the home signal should indicate PROCEED.

If home signal displays STOP indication, be governed by Rule 664.

Speed must not exceed fifteen (15) MPH between home signals and crossing.

X STREET, SACRAMENTO, WP Crossing, Interlocking:

Home signals governing movement of trains with the current of traffic over the crossing located at the curb line 72.5 feet on either side of crossing; back-up signals governing reverse train movements over the crossing are located at the curb line 72.5 feet on either side of crossing. No distant signals.

Cars must not be left standing between the home signals unless coupled to another car or an engine which is standing outside of

the home signals.

Cars or trains finding the home signals at "STOP," will stop clear of signal to permit it to change to "PROCEED" position when train on the Western Pacific has passed out of home signal limits.

An indicator lamp mounted on time release housing located in the northeast corner of the crossing governs as follows:

This lamp will be lighted when the Western Pacific train dispatcher lines up for WP movement through the interlocking. It will remain lighted until such movement has passed the interlocking signal or until the signals have been returned to Stop by the train dispatcher.

If this indicator lamp is lighted, member of crew of train or yard engine having switching to do in this area must contact Western Pacific train dispatcher for instructions before passing the interlocking signal.

INTERLOCKING PLANTS AND SIGNALS (Continued) **EMERGENCY RELEASE**

If no cause for signals being at STOP is seen, obtain permission from Western Pacific Train Dispatcher by telephone to operate the Emergency release. Telephone for this purpose located in box on side of instrument house adjacent to the crossing.

When authorized by Western Pacific Train Dispatcher to operate Emergency Release, trainmen will operate release in box mounted on signal governing reverse movements over the crossing for the track involved. Instructions for operation of the Emergency Release are posted in the release housing and are as follows:

Speed of cars or trains over Automatic Interlocking must not

exceed ten (10) miles per hour.

Note: The word trains includes yard engines.

MP 109.17, SANKEY, WP CROSSING AND CONNECTION.

Sacramento Northern:

Eastward-Inoperative distant signal located 3385 feet west of absolute signal.

Absolute Signal is a two-unit signal. Upper unit governs movements to WP main track. Lower unit governs movements on SN main track.

Westward-Inoperative distant signal located 3685 feet east of of absolute signal. Absolute Signal governs movements on SN main track.

Western Pacific:

Westward-Absolute Signal is a two-unit signal. Upper unit governs movements on WP main track. Lower unit governs movements to SN main track.

Dual control switches provide entrance to and crossing over WP main track. Instructions for operating Dual Control switches by hand are posted in telephone booth adjacent to the crossing. Speed on approach curves and through turnouts of Dual Control

switches shall not exceed 10 miles per hour.

When train or engine is stopped by Absolute Signal displaying STOP indication, a member of the crew must contact WP Train Dispatcher by telephone. Rules 509 and 546 apply.

MP 149.31, LIVE OAK, SP CROSSING, INTERLOCKING. Home signals located 600 feet east and west of crossing.

The westbound distant signal is located 3000 feet in advance of the home signal. The eastbound distant signal is located 1300 feet in advance of the home signal.

Distant signals are permanently lighted and display yellow

aspect only per Rule 285

The approach circuit for westward movements begins 1800 feet east of the westbound home signal.

The approach circuit for eastward movements begins at the ant signal, 1300 feet west of the eastbound home signal.

Speed of trains between home signals and over SP crossing shall not exceed twenty (20) MPH.

Normal Indication of Interlocking Home Signals-"STOP":

When train approaches the crossing and enters approach circuit, the home signal should change to "PROCEED."

If no cause for signals being at "STOP" is seen or if there is

a train on intersecting tracks standing outside of the home signals, with no indication that it is to immediately proceed, flagman must be sent ahead to operate a release located in box at the crossing. Box is provided with standard switch lock. Instructions for the operation of release are posted inside box.

WOODLAND BRANCH. MP 1.55 MIKON, SP CROSSING IN-TERLOCKING.

Home signals located 500 feet east and west of crossing. Inoperative approach signals located 2000 feet from home signals display aspect per Rule 285.

Speed of trains shall not exceed fifteen (15) MPH between

approach signals and home signals.

All trains, engines and cars must be brought to a stop before passing home signals at Southern Pacific crossing at Mikon and wait sixty (60) seconds before proceeding.

CLOCKWORK TIME RELEASE: When trains are stopped by signals governing the use of automatic interlocking, flagman must be sent to crossing to operate clockwork time release located in box just west of crossing locked with Sacramento Northern switch lock.

Release must not be operated when trains are within interlocking limits as defined by interlocking home signals, or seen or heard

approaching on intersecting tracks.

Approximately four minutes after release has been operated, a red indication light for train direction will be displayed over release, and home signal should indicate proceed. If, for any reason, home signal cannot indicate proceed, red indication light on home signal (located on mast below home signal) will be displayed and this will be authority to proceed through interlocking limits.

If home signal is in stop position and red indication light on home signal (located on mast below home signal) is not displayed, train may proceed over crossing as provided by Rule 664.

Instructions for operating time release are posted inside of box.

TOWER BRIDGE, SACRAMENTO

Bridge Interlocking Signals and Derails:

Signals are located 305 feet east of Bridge on Front Street, and 500 feet west of Bridge. The switch leading to the River Spur serves as a derail west of the Bridge.

The interlocking home signal at River Spur derailing switch is a two-unit signal; the upper signal governs movements to Front Street, and the lower signal governs movements to the River Spur.

Signal located at the east end of the Bridge governing eastward movements is a two-indication light signal. Green indication governs movements to Front Street. The red indication is a stop signal.

Switch Indicator:

The switch leading into the main track from Westside Spur is protected by switch indicator. The switch leading from the River Spur to the main track is protected by light signals operated from the tower.

Movements of Trains and Yard Engines:

Movements through interlocking plant shall be made in accordance with signal indication. In case of signal failure, be governed by Rule 663.

Trains and yard engines must not exceed a speed of 15 miles per hour over the bridge and 10 miles per hour over the highway

crossing west of the bridge.

On Westward movements from Front Street to Tower bridge, Sacramento, if on account of stalling or being blocked by vehicular traffic, it becomes necessary to make a reverse movement, train or engine after sounding signal 14(h) may back and then proceed within interlocking limits without permission from the Towerman, provided the movements are protected by trainmen. If reverse movement results in train or engine moving out of interlocking limits, forward movement must not be made without the proper interlocking signal or permission from the Towerman.

Telephones:

Telephones are installed in the tower, on Front Street, between River Spur and Westside Spur for trainmen to communicate with the towerman.

Whenever there is switching to be done on the River Spur or Westside Spur, which requires several movements from the main track to these spurs, the conductor shall communicate with the towerman and advise him so that there shall be no delay in the operation of signals or switches.

There is a signal box located on the interlocking home signal on Front Street which is operated by using a switch key. Operation of this signal box gives the towerman an indication in the tower that a train is on Front Street, and ready to move through the plant. This signal box is to be used when whistle signal cannot be heard.

Route Whistle Signals:

From Front Street to Westside and Westside to Front Street..... From main track to River Spur and reverse

SPEED TABLE

PER MILE PER HOUR 36" 100 37" 97.3 38" 94.7 39" 92.3 40" 90 41" 87.8 42" 85.7 43" 83.3 44" 81.8 45" 80 46" 78.3 47" 76.6 48" 75.4 49" 73.8 50" 72 51" 70.6 52" 69.2 53" 66.5 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 50" 61 1'0" 50 1'0" 50 1'0" 53.7 1'0" 53.7 1'0" 53.7 1'0" 53.7 1'0" 53.7 1'0" 53.7		
36" 100 37" 97.3 38" 94.7 39" 92.3 40" 90 41" 87.8 42" 85.7 43" 83.3 44" 81.8 45" 76.6 48" 75 49" 73.8 50" 72 51" 70.6 52" 69.2 53" 67.9 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 50 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'06" 54.5 1'06" 54.5 1'07" 53.7 1'08" 52.2	PER	
37" 97.5 38" 94.5 39" 92.5 40" 90 41" 87.6 42" 85.5 43" 83.7 44" 81.8 45" 80 46" 78.3 47" 76.6 48" 75.5 50" 72 51" 70.0 52" 69.2 53" 67.9 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 55.4 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'06" 54.5 1'06" 54.5 1'06" 54.5 1'06" 54.5 1'06" 54.5 <td></td> <td></td>		
38" 94.5" 39" 92.3" 40" 90 41" 87.8 42" 85.7 43" 83.7 44" 81.8 45" 76.6 48" 75.8 49" 73.8 50" 72 51" 70.6 52" 69.2 53" 67.9 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 53.7 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'06" 54.5 1'06" 54.5 1'07" 53.7 1'08" 52.9 1'10" 50.7 1'13" 49.2 1'14" 48.6 1'15" 48.6 1'15" 48		
40" 90 41" 87.8 42" 85.7 43" 83.3 44" 81.8 45" 80 46" 78.3 47" 76.6 48" 75 49" 73.8 50" 72 51" 70.6 52" 69.2 53" 66.7 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 53.7 1'06" 54.5 1'06" 54.5 1'06" 54.5 1'08" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.5 1'14" 48.6		94.7
41" 87.8 42" 85.7 43" 83.1 44" 81.8 45" 80 46" 78.3 47" 76.6 48" 75.5 49" 73.5 50" 72 51" 70.6 52" 69.5 53" 67.5 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'06" 54.5 1'06" 54.5 1'06" 54.5 1'08" 52.5 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6		. 92.3
42" 85.7 43" 83.1 44" 81.8 45" 80 46" 78.3 47" 76.6 48" 75 49" 73.5 50" 72 51" 70.6 52" 69.2 53" 66.5 54" 66.5 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 53.7 1'04" 56.2 1'05" 53.7 1'08" 52.2 1'06" 54.5 1'08" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 42.4		
43" 83.1 44" 81.8 45" 80 46" 78.3 47" 76.6 48" 75 49" 73.5 50" 72 51" 70.0 52" 69.2 53" 67.9 54" 66.7 55" 65.8 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'06" 54.5 1'08" 52.5 1'09" 52.5 1'10" 51.4 1'11" 49.3 1'14" 48.6 1'15" 48.6 1'15" 48.6 1'16" 47.4 1'17" 46.2 1'19" 45.6 1'25"		. 87.8
44" 81.8 45" 80 46" 78.3 47" 76.6 48" 75.5 49" 73.8 50" 72 51" 70.0 52" 69.2 53" 67.9 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 50 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'07" 53.7 1'08" 52.9 1'09" 52.9 1'09" 52.9 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17"	42"	
46" 78.3 47" 76.6 48" 75 49" 73.8 50" 72 51" 70.0 52" 69.2 53" 67.9 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'04" 56.2 1'05" 53.4 1'05" 54.5 1'06" 54.5 1'07" 54.5 1'08" 52.2 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48.6 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'25" 42.4 1'30"	44"	. 81.8
47" 76.6 48" 75 49" 73.5 50" 72 51" 70.6 52" 69.5 53" 67.5 54" 66.7 55" 63.2 57" 63.2 58" 62.1 59" 61 1'00" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'07" 53.7 1'08" 52.2 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.8 1'20" 45.6 1'20" 45.6 1'25" 42.4 1'30" 30.2 1'55" 31.3 2'00" <td>45"</td> <td>. 80</td>	45"	. 80
48" 75 49" 73.8 50" 72 51" 70.6 52" 69.2 53" 67.2 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 53.7 1'06" 54.5 1'06" 54.5 1'08" 52.2 1'08" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.5 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'25" 42.4 1'30" 30 2'15"		. 78.3
49" 73.8 50" 72 51" 70.6 52" 69.2 53" 67.5 54" 66.5 55" 65.5 56" 64.3 57" 63.2 58" 62.1 1'0" 60 1'0" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 53.7 1'08" 52.8 1'09" 52.5 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48.6 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'30" 40 1'35" 30 1'25" 42.4 1'30" 36 1'40" 36 1'45" 34.3 1'50"		
50" 72 51" 70.6 52" 69.2 53" 67.9 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'08" 52.6 1'08" 52.2 1'10" 51.4 1'10" 51.4 1'10" 51.4 1'10" 52.2 1'10" 52.2 1'10" 52.2 1'10" 51.4 1'11" 50.7 1'13" 49.3 1'14" 48.6 1'15" 48.6 1'16" 47.4 1'17" 46.8 1'1	49"	73.5
52" 69.2 53" 67.9 54" 66.5 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 50 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 53.7 1'06" 54.5 1'07" 53.7 1'08" 52.9 1'09" 52.9 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.8 1'20" 45 1'20" 45 1'25" 42.4 1'30" 30 2'15" 30.3 2'15" </td <td>50"</td> <td>. 72</td>	50"	. 72
53" 67.9 54" 66.7 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 50 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'07" 53.7 1'08" 52.2 1'10" 51.4 1'10" 51.4 1'11" 50.7 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'20" 45 1'25" 42.4 1'30" 30.2 1'55" 31.3 2'00" 30.2 2'15" 26.7 2	51"	. 70.6
54" 66.5 55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'07" 53.5 1'08" 52.2 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48.6 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'20" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 24.7 2	52"	
55" 65.5 56" 64.3 57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 54.5 1'06" 54.5 1'07" 53.7 1'08" 52.2 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.5 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'25" 42.4 1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 <td< td=""><td>54"</td><td></td></td<>	54"	
57" 63.2 58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 53.7 1'08" 52.8 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48.6 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 <	55"	. 65.5
58" 62.1 59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 53.7 1'06" 54.5 1'07" 53.7 1'08" 52.2 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48.6 1'15" 46.8 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 30 1'40" 36 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 <	56"	. 64.3
59" 61 1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'07" 53.7 1'08" 52.8 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 30.9 1'40" 36.6 1'45" 34.3 1'55" 31.3 2'00" 30.2 2'15" 26.7 2'45" 31.8 3'00" 21.8 3'00" 30.2 2'15" 26.7 2'45" 31.5	57"	
1'00" 60 1'01" 59 1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'07" 53.5 1'08" 52.2 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'13" 49.5 1'14" 48.6 1'15" 48 1'16" 47.4 1'18" 46.2 1'19" 45.6 1'20" 45 1'20" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26.7 2'45" 21.8 3'00" 24 2'45" 21.8 3'00" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 <t< td=""><td>59"</td><td></td></t<>	59"	
1'02" 58.1 1'03" 57.1 1'04" 56.2 1'05" 55.4 1'06" 54.5 1'07" 53.5 1'08" 52.9 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'18" 46.2 1'19" 45.6 1'20" 45 1'20" 45 1'25" 42.4 1'30" 40 1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 24 2'30" 24 2'45" 21.8 3'00" 17.1 4'00" 15 5'00" 12 6'00" 10 <td< td=""><td>1'00"</td><td></td></td<>	1'00"	
1'03" 57.1 1'04" 56.2 1'05" 55.4 1'07" 54.5 1'07" 53.7 1'08" 52.2 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'35" 36 1'45" 36.1 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 <t< td=""><td></td><td></td></t<>		
1'04" 56.2 1'05" 55.4 1'07" 53.7 1'08" 52.8 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 36 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6 <td>1′02″</td> <td></td>	1′02″	
1'05" 55.4 1'06" 54.5 1'07" 53.7 1'08" 52.9 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 36 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 7.5 <td>1'04"</td> <td></td>	1'04"	
1'07" 53.7 1'08" 52.9 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'18" 46.8 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 40 1'35" 37.9 1'40" 36.6 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 32.7 14'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6	1'05"	. 55.4
1'08" 52.8 1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'30" 40 1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26 2'45" 21.8 3'00" 24 2'45" 21.8 3'00" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6		. 54.5
1'09" 52.2 1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 40 1'45" 36 1'45" 36 1'45" 31.3 2'00" 30 2'15" 26 2'45" 21.8 3'00" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6		. 53.7
1'10" 51.4 1'11" 50.7 1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'35" 37.9 1'40" 36 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 7'30" 8.6		
1'12" 50 1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'35" 37.9 1'40" 36 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 8'00" 7.5		. 51.4
1'13" 49.3 1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'19" 45.6 1'20" 45 1'20" 45 1'25" 42.4 1'30" 40 1'35" 37.9 1'40" 36.6 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 8'00" 7.5		. 50.7
1'14" 48.6 1'15" 48 1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 40 1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 8'00" 7.5		
1'16" 47.4 1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 40 1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.66 7'30" 8.66 7'30" 8.66	1'14"	48.6
1'17" 46.8 1'18" 46.2 1'19" 45.6 1'20" 45 1'20" 45 1'25" 42.4 1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 7'30" 8.6 8'00" 7.5	1'15"	. 48
1'18" 46.2 1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 40 1'35" 37.9 1'40" 36 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 8'00" 7.5		. 47.4
1'19" 45.6 1'20" 45 1'25" 42.4 1'30" 40 1'35" 37.9 1'40" 36 1'45" 34.3 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8.6 8'00" 7.5		
1'20" 45 1'25" 42.4 1'30" 40 1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30.2 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8 8'00" 7.5		45.6
1'30" 40 1'35" 37.9 1'40" 36 1'45" 34.3 1'55" 32.7 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8 8'00" 7.5	1′20″	. 45
1'35" 37.9 1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8 8'00" 7.5	1'25"	. 42.4
1'40" 36 1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8 8'00" 7.5	1′30″	
1'45" 34.3 1'50" 32.7 1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8 8'00" 7.5	1'40"	
1'55" 31.3 2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'30" 8.6 7'30" 8 8'00" 7.5	1'45"	. 34.3
2'00" 30 2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8.6 8'00" 7.5		. 32.7
2'15" 26.7 2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8.6 8'00" 7.5		
2'30" 24 2'45" 21.8 3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8 8'00" 7.5		
3'00" 20 3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8.6 8'00" 7.5	2'30"	
3'30" 17.1 4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8.6		. 21.8
4'00" 15 5'00" 12 6'00" 10 7'00" 8.6 7'30" 8 8'00" 7.5		. 20
5'00" 12 6'00" 10 7'00" 8.6 7'30" 8.8 8'00" 7.5		. 15
7'00" 8.6 7'30"		. 12
7′30″		
8'00" 7.5	7′00″	. 8.6
10'00" 6	8'00"	7.5
	10'00"	

TABLE OF LOCOMOTIVE RATING IN TRAILING TONS

		142 CLASS	201 CLASS	501 CLASS
Between	And	44-ton Diesels	70-ton Diesels	100-ton Diesels
Walnut Creek	Meinert	250	750	1000
Meinert	Concord	650	1500	2000
Concord	Clyde	200	500	650
Clyde	Pittsburg	650	1500	2000
Harbor St.,	ard Montezuma St. to Pittsburg	400	750	1000
Except Westw Montezuma	St., Pittsburg	200	600	800
Montezuma	Dozier	700	1500	2000
Dozier	Sacramento	800	2000	2500
Dozier	Vacaville Jct.	800	2000	2500
Except from M	IP 6.0 to Vacaville Jct.	550	1000	1250
Vacaville Jct.	Vacaville	800	1500	_
Vacaville Jct.	Willotta	800	1500	_
Sacramento	Marysville	800	2000	60-Ton Electric
Marysville	Yuba City	450	900	950
Yuba City	Chico	800	2000	_
Colusa Jet.	Meridian	800	2000	_
Broderick	Woodland	800	2000	_
Riverview	Oxford	700	1500	
So. Sacramento	Clyde	301 class	3000 trai	ling tons per unit

Note—Safe operating limits as prescribed in operating instructions for type of locomotive in use must be observed.

Tonnage ratings for 201 class engines apply to TS 741 Class, 70 ton diesels.

SPEED RESTRICTIONS FOR ENGINES

Maximum speed in miles per hour for engines is subject to speed restrictions for trains shown on page 6.

	CL	ASS	ENGINE NUMBERS	MAXIMUM SPEED
70	66	Diesels	142-147 201-202	35 MPH 55 "
100 100	66	61	501-503 504-511	65 "
120	66	"	301 Class	50 "

Speed restrictions for 201 class apply to TS 741 class, 70 ton diesels.

When handled dead in train:

142 class engines, maximum speed 30 MPH.

electric engines, maximum speed 35 MPH.

TABLE OF WEIGHT LIMITATIONS

BETWEEN	AND	GROSS WEIGHT (Car & Contents)	
Walnut Creek	No. Sacramento Swanston Vacaville Jet Oxford	210,000	
Vacaville Jct N. Sacramento	Willotta	169,000	
Marysville	Yuba City	210,000	
Yuba City	Meridian	169,000	
			ı

List of Railroad crossings and junctions, protection provided for movements over them, and the name of the Railroad having prior right in the use of the crossing or Junction not protected by signals or flagman:

LOCATION	NAME OF RR.	PROTECTION	RESTRICTION	RIGHT
Las Juntas	S. P. Co	FIRST SUBDIVISION No Signals	Stop	
	Depot R. R.	Automatic Interlocking Signals.	15 mi. per hr	Governed by Signal
Shell Point Shell Chem. Co Pittsburg:	S. P. Co	No Signals	Stop	S. N. Ry.
East of Harbor St East of Columbia St S. N. Ry. industrial track between West Pittsburg	A. T. & S. F. R. R	No Signals	Stop and FlagStop and Flag	A. T. & S. F. Ry. (See instructions on page 7)
and Pittsburg	A. T. & S. F. R. R. Industrial Track	No Signals	Stop. (See instructions on page 7)	A. T. & S. F. Ry.
Between West Pittsburg and Pittsburg Sacramento:		Crossing Gate	,15 mi. per hr	S. N. Ry.
Front St. & Capitol Ave	S. P. Co	FlagmanSECOND SUBDIVISION	Stop	
Globe, Jct. Jt. Track	W. P. R. R	T. C. S. T. C. S.	Stop	Governed by Signal Governed by Signal
MP 134.40, Jct. Jt. track (W P MP 175.63) Marysville—Joint Track	W. P. R. R	T. C. S	Caution	Governed by Signal Governed by Signal
Yuba City	S. P. Co	No Signals	Stop—Except when proceed signal is received from flagman.	S. P. Co.
Live Oak	S. P. Co	Automatic Interlocking Signals. No Signals. SACRAMENTO BELT LINE	Stop	Governed by Signal S. P. Co.
Front St	S. P. Co. Industry Tracks	No Signals	Caution	S. P. Co.
Front & "R" Sts	S. P. Co. & W. P. R. R	No Signals	Stop and Flag—Except when proceed signal is received from	
Front & "X" Sts	C. C. T. Co. W. P. R. R.	No Signals	flagman. Caution. 10 mi, per hr.	S. P. Co. & W. P. R. R. Caution Governed by Signal
Alhambra Blvd. & "X" St. Jct. Joint Track		No Signals	Stop	C. C. T. Co.
Alhambra Blvd. & "R" St.	S. P. Co	No Signals	Stop and Flag—Except when proceed signal is received from	
"R" St., Jet. Joint Track.	W. P. R. R.	No Signals	flagman	S. P. Co. Caution
"B" St., Jct. Joint Track Haggin, Jct. Jt. Track Sacramento, Westgate Yard.	W. P. R. R	T. C. S. T. C. S.	patcher to enter Joint Track.	Governed by Signal
Sacramento, westgate Yard.		No Signals	See instructions on page 8 Stop. See instructions on page 11.	S. N. Ry. Governed by Signal
		CHICO YARD No Signals.		

		YARD LIMITS	
	WEST MP	YARD	EAST MP
	26.9	Walnut Creek	27.6
	30.4	Meinert-Concord	32.4
	38.6	Port Chicago	39.7
	42.2	McAvoy	42.8
	44.5	Pittsburg	48.6
	49.7	Montezuma-Dozier	65.0
		Willotta Bch.	0.3
	7.3	Vacaville Jct.	
		Vacaville }	4.5
	7.3	Vacaville Jct.	
		Willotta	17.1
	73.7	Libfarm	74.8
	85.7	Riverview \	87.5
		Holland Bch.	1.0
	90.4	Sacramento	97.7
		Woodland Bch.	0.9
	15.9	Woodland	16.7
	11.5	Conaway	12.1
	102.5	Rio Linda	103.6
	109.2	Sankey-E. Nicolaus	119.1
	129.7	Pearson-Alicia	134.4
	134.7	Marysville	139.6
ì	139.6	Colusa Jct.	140.2
9	0.0	Col. JctMeridian	13.6
	148.3	Live Oak	149.3
	181.8	Chico	188.8

SIDE AND OVERHEAD OBSTRUCTIONS (Not Standard Clearance)

General—All loading platforms—side.
General—Bulk loading chutes—side.
General—Receiving pipes at oil company spurs—

Chico—Trees, side and overhead.

Marysville—Diamond Match Warehouse—side.

Marysville—Orange St. track—two dwellings—

Clarksburg—Sugar plant eaves—side.
Sacramento—Subway, side and overhead. Trainmen must not ride on top or side of cars when going through subway.

Trainmen will at all times look out for low hang-

ing trolley and span wires.

ing trolley and span wires.

INTERCHANGE TRACKS

Las Juntas —S. P. R. R.
Clyde —Naval Ammunition Depot R. R.
Port Chicago—A. T. & S. F. Ry.
McAvoy —S. P. R. R.
Sacramento —W. P. R. R.
S. P. R. R.
C. C. T. Co.
Marysville —W. P. R. R.
S. P. R. R.
Chico —S. P. R. R.

STOCK CORRALS

Peethill—SD Yolano—SD Montezuma—SD Hebron—SD

ADDITIONAL COMMERCIAL STATIONS

Stations	Facilities for Handling	Mile Post	Capacity in Freight Cars
Dudley	CL	91.83	23
West Sacramento		92.24	15
Peethill	CL	92.84	15
Pencilwood		97.84	5
Swanston	CL & LCL	98.06	9
Reed	CL & LCL	132.10	26
Oroville Jct	CL & LCL	165.07	6
CL-Carload fr			
LCL—Less Car	load Freight		

MAP OF **SACRAMENTO** NORTHERN RAILWAY AND CONNECTIONS

